

DO DESK

DESKTOP GRAPHICAL LCD DO INDICATOR



OVERVIEW

DO100 accurately measures dissolved oxygen for efficient control of aeration systems in wastewater treatment applications. It can also ensure safe ppm levels to maintain life in fish farming. Designed to be intrinsically safe, its corrosion-resistant sealed composite enclosure makes it ideal for harsh environments where moisture, dust and chemicals may be prevalent.

Its design facilitates easy installation, minimizing cable and panel construction costs. The transmitter's direct 4-20 mA output simplifies start-up, operation and maintenance tasks to provide considerable savings over the lifetime of the device. The device's plug-in modular design allows safe removal and easy replacement of the probe. A ½-inch NPT conduit connection increases protection and noise immunity of the output cable.

FEATURES




- DO% : 0 to 200.0% / 0 to 20.00ppm (mg/L)
- Field Programmable through four keys
- Unaffected by sample color or turbidity
- 128 x 64 Graphical LCD
- 2 Programmable Setpoints
- Relay Option
- Programmable 4-20mA output
- RS485 / MODBUS Network
- Compact Desktop model




SPECIFICATIONS

| Model | DO DESK |
|-----------------------|---|
| Range | 0 to 200.0% / 0 to 20.00ppm (mg/L) |
| Signal Type | DO Probe |
| Display | 128 x 64 Graphical LCD |
| No of Channels | 1 |
| Max. Resolution | 0.1%, 0.01ppm (mg/L), 0.1°F/ °C |
| Accuracy | +2.0%FS, 0.4ppm (mg/L), +1.8°F/1°C |
| Operating Temperature | 0 - 50° C |
| Storage Temperature | 0 - 60° C |
| Relative Humidity | 0 - 85% RH (non-condensing) |
| Program Variables | Saved in non-volatile EEPROM. No battery backup required |
| Voltage | 220 V ~ AC ±15% / 110V AC / 24V DC (Factory configurable) |
| Frequency | 50 / 60 Hz |
| Power Consumption | Less than 2 Watts |



Ph: +91 44 2482 7879 
sales@gsv-microtech.com 
www.gsv-microtech.com 

3/531/A Kundrathur Road, Madanandapuram, 
Porur, Chennai - 600 116. India.



Scan to download
DO DESK datasheet